
# C14 and C16 IEC Inlet - Vertical



Vertical Module Arrangement



- Inlet with 2.8mm or 6.3mm
- Fuseholder/Voltage Selector/Indicator options/Blanking plate



# How to order -

#### **BZV XX** XXXXX XX

# Type of Inlet / Outlet

C14 Power Inlet (cold condition), 6.3 or 2.8mm tabs:

03 = PX0575/63

04 = PX0575/28

C16 Power Inlet (hot condition), 6.3 or 2.8mm

05 = PX0595/63

06 = PX0595/28

Please note type 05 and 06 are not available in filtered version

### Filtered or Non Filtered Inlet

Z0000 = Non Filtered

Axxxx = Standard

For Filtered inlet use 6th to 9th characters from filter ordering code see page 178 E.g. BZV03/A0120/04

# **Combination of Other Components**

Twin Fuseholder:

 $04 = 2 \times FX0359$ 

Voltage Selector and Fuseholder:  $14 = 1 \times VS0001 + 1 \times FX0359$ 

Voltage selector and Neon:

 $37 = 1 \times VS0001 + DX0928/110V/Red$ 

 $38 = 1 \times VS0001 + DX0928/110V/Green$ 39 = 1 x VS0001 + DX0928/250V/Red

 $40 = 1 \times VS0001 + DX0928/250V/Green$ 

Fuseholder and Neon:

 $41 = 1 \times FX0359 + DX0928/110V/Red$ 

 $42 = 1 \times FX0359 + DX0928/110V/Green$ 

43 = 1 x FX0359 + DX0928/250V/Red  $44 = 1 \times FX0359 + DX0928/250V/Green$ 

Fuseholder and Blanking Plate:

 $45 = 1 \times FX0359 + Blanking Plate$ 

Voltage Selector and Blanking Plate:

 $B2 = 1 \times VS0001 + Blanking Plate$